





















COLO-07 manual gun



colo-07A automatic gun



COLO 52A



COLO 52B



COLO MINI01



COLO MINI02



COLO MINI03



COLO MINI B



COLO 62A



COLO 62B



COLO 62C



COLO 62C-2



COLO 40A



COLO 40B



COLO 40C



COLO 40D



COLO R01



COLO S01/S02



Spare Parts



COLO-55A